



KRAUTOL®

PROFESSIONAL



The project: Painting new façades

You should always prime the surface before painting new, undamaged façades. This ensures that the subsequent coat dries uniformly on the surface, producing an optimum surface finish. Besides white, you can also use colour to brighten façades. The required colour can be mixed in the KRAUTOL Color 2.0 paint mixing system. The selected colours should blend in with the building and the surrounding area.

The optimum KRAUTOL system solution:



Tiefgrund Plus
Acrylic hydrosol for
façade levelling primer
coats

**ULTRA MAXX
Complete**
The 5-in-1 all-inclusive
solution for façades

PAINTING NEW FAÇADES



KRAUTOL®

PROFESSIONAL

This is how it works: an optimum result in a few steps



Preparation and cleaning

Clean the façade with a pressure washer and completely remove any dirt or stains.

Leave façade to dry out completely after cleaning, so the subsequent primer can penetrate the façade more effectively.

New, non-weathered rendering does not need to be cleaned.



Primer

Prime the façade with **Tiefgrund Plus**. This high-quality primer strengthens the surface, ensuring uniform absorption.

This brings the advantage that the façade paint dries evenly and adheres securely while less paint is consumed.

Allow façade to dry thoroughly again after priming.



Prime and finish coat

Pre-treat the façade with **Ultra Maxx Complete** (diluted with a maximum of 10% water). The low viscosity of the paint ensures good penetration behaviour, thus achieving effective adhesion in the final coat.

Leave primer coat to dry out thoroughly. Then apply undiluted **Ultra Maxx Complete** façade paint.



Other façade projects

Simply scan the QR code with your smartphone or tablet and access additional information.

12/2017

Systematic façade protection