



The project: Discolouration and blooming

Touching up spots of loose rendering with new façade rendering and a subsequent coat of paint may cause blooming on the façade if rendering is not allowed to dry for long enough. The influence of moisture on surfaces with different absorption rates may cause discolouration.

The optimum KRAUTOL system solution:



Tiefgrund Plus
Acrylic hydrosol for
façade levelling primer
coats



**ULTRA MAXX
Complete**
The 5-in-1 all-inclusive
solution for façades



KRAUTOL®

PROFESSIONAL

This is how it works: an optimum result in a few steps



Preparation and cleaning

Clean the façade with a pressure washer and completely remove any dirt or stains.

Leave façade to dry out completely after cleaning, so the subsequent primer can penetrate the façade more effectively.



Primer

Prime the façade with **Tiefgrund Plus**. This high-quality primer strengthens the surface, ensuring uniform absorption. This brings the advantage that the façade paint dries evenly and adheres securely while less paint is consumed.

Allow façade to dry thoroughly again after priming.



Prime and finish coat

Pre-treat the façade with **Ultra Maxx Complete** (diluted with a maximum of 10% water). The low viscosity of the paint ensures good penetration behaviour, thus achieving effective adhesion in the final coat.

Leave primer coat to dry out thoroughly. Then apply undiluted **Ultra Maxx Complete** façade paint.



Other façade projects

Simply scan the QR code with your smartphone or tablet and access additional information.

12/2017

Systematic façade protection