



The project: Surface abrasion

White pigments are released on the surface of the façade coat due to UV radiation and the binder being washed out of the old coat of paint, causing chalky abrasion. If you rub the surface with your hand, you can see whether the surface is chalking or powdering.

The optimum KRAUTOL system solution:



Tiefgrund Plus
Acrylic hydrosol for
façade levelling primer
coats



**ULTRA MAXX
Complete**
The 5-in-1 all-inclusive
solution for façades



KRAUTOL®

PROFESSIONAL

This is how it works: an optimum result in a few steps



Preparation and cleaning

Clean the façade with a pressure washer and completely remove any dirt or stains.

Leave façade to dry out completely after cleaning, so the subsequent primer can penetrate the façade more effectively.



Primer

Prime the façade with **Tiefgrund Plus**. The high-quality primer strengthens the surface, ensuring uniform absorption. This brings the advantage that the façade paint dries evenly and adheres securely while less paint is consumed.

Allow façade to dry thoroughly again after priming.



Prime and finish coat

Pre-treat the façade with **Ultra Maxx Complete** (diluted with a maximum of 10% water). The low viscosity of the paint ensures good penetration behaviour, thus achieving effective adhesion in the final coat.

Leave primer coat to dry out thoroughly. Then apply undiluted **Ultra Maxx Complete** façade paint.



Other façade projects

Simply scan the QR code with your smartphone or tablet and access additional information.

12/2017

Systematic façade protection